INSTALLATION MANUAL VSI DIAGNOSTIC D2.8



Version: 20201203

1 Table of contents

1	TABLE OF	CONTENTS	2
2	GENERAL		3
	2.1 2.2 2.3	System requirements Introduction Abbreviations / terms:	3 3 3
3	VSI PRIN	S VSI DIAGNOSTIC D2.8 SOFTWARE INSTALLATION	4
	3.1 3.2 3.3 3.4 3.5 3.6 3.7 3.8	Login Prins website Activate web account Download Installation First start-up and activation Software License Run the Prins VSI diagnostic D2.8 software Operation of Prins VSI diagnostic D2.8 software	4 4 5 5 6 7 8 9

2 General

2.1 System requirements

Operating system: Screen: USB port: Rights: Internet connection: Windows 7 / Windows 10 <u>1024 x 768</u> USB port / COM Port Administrator rights WLAN or SIM card



Important note for Windows XP and Vista

Support for Windows XP and Vista ended by Microsoft. Therefor Prins cannot guarantee that Prins AFC v2 Software will work flawlessly on Windows XP and Windows Vista. Use Windows 7 or a more recent operating system. Prins guarantees system support for Windows 7 and Windows 10.

2.2 Introduction

The VSI DIAGNOSTIC D2.8 is a Windows-based software program and is a multipurpose software tool for the Prins VSI-1. The software allows the user to diagnose, calibrate and update the ECM VSI.

A Prins Diagnostic Tool (PDT) is needed to communicate with the ECM VSI.

For general information about Prins Autogassystemen you can visit the following internet site: https://www.prinsautogas.com

2.3 Abbreviations / terms:

	VSI diagnostic D2.8	Pins
PDT	Prins Diagnostic Tool (serial interface)	Prins Despert
ECM VSI	Electronic Control Module = VSI computer	
PC / Laptop	Personal Computer	

3 VSI Prins VSI diagnostic D2.8 software installation

3.1 Login Prins website

Order a username and password for the Prins website at your importer or local distributor.

Log in on the Prins website to download the software.





When you do not remember your password, select **"Forgot your password?"** to reset your password. You will receive an e-mail with the procedure to reset the password.

3.2 Activate web account

Follow the instructions written in the e-mail you received from Prins.

3.3 Download

Select and download the required software in **Support** – **Software. Scroll down** to the VSI-1 Diagnostic Software D2.8 section



3.4 Installation

Open the file Version_D2.83.exe. Confirm and select Yes during all steps of the installation.



3.5 First start-up and activation

1. At first start-up, an "Install Code" is displayed.

This is unique for every computer; the code will not be the same in your case. When reference is made to this code, you should replace the code with the code displayed on your screen.

Registration via the Prins Website is not possible yet.



2. Copy the Installcode

Installcode= D6BACA904A5E4

3. Send a mail with the Install code & Your Username to your importer / local distributer.

Username & Installcode



4. Your importer / local distributer will send the codes to Prins via the Prins Support Center



5. You receive the activation codes from your contact person.

715DAFQ-EHA8LWK-YGA7XKE-Q7J0EMQ DK9DZ3E-H1RE1VN-YP2JAT8-62P00JH ZF0APDQ-L5D20QN-80CLLGL-8LU07NP





3.6 Software License

Check your license in "**Help - Info**" in the Diagnostics program.



3.7 Run the Prins VSI diagnostic D2.8 software

Double click on the VSI diagnostic icon located on the desktop



The VSI diagnostic is ready to use when the software is installed and activated.

The Prins Diagnostic Tool (PDT) is required to communicate with the ECM.

Set: 191-020001

Cable USB





195-700004



SUB-D VSI I-II

3.8 Operation of Prins VSI diagnostic D2.8 software

Make use of the very detailed Help file intergraded in the VSI diagnostic software.

Open the help information in "**Help – Index**".

Program Functions Options Help Numeric and graphic Index BIE VarList1 Registration GarLi VarList2 Info GarLi VarList3 mempty 7 VarList3 <	🔝 rins Sequentiel Diagnostics****						
Numeric and graphic Index Price VarList1 Registration artial 2 VarList2 Info artial 2 VarList3 empty 7 VarList 2 VarList4 empty 7 VarList 2 VarList3 empty 7 VarList 2 VarList3 empty 7 VarList 2 VarList4 empty 7 VarList5 2 VarList3 empty 7 VarList5 2 VarList4 empty 7 VarList5 2 VarList4 empty 7 VarList5 2 VarList5 empty 7 VarList5 2 VarList5 empty 7 VarList5 2 VarList5 Solution Reset 2 VarList5 Solution Restolution 3	Program Functions Options Help						
VarList1 Registration	Numeric and graphic Index		eric-				
2 VarList2 Info arLi 3 VarList3 empty 7 VarList3 2 VarList3 empty 7 VarList3 3 Help VSI 1.8 - - × 4 Back Forwald Pert Options - × 2 Med Back Forwald Pert Options - - × 2 Med Back Forwald Pert Options - - × 2 Med Back Forwald Pert Options -	1 VarList1 Regis	tration	/arLi				
3 Variation Image: Second Secon	2 VarList2		(art i				
Perture Perture Perture Ward List3 Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture Perture							
Vacuation -	VarList3 • empty		/ VarLi				
	/ Verlict/ emntr		Q Verl i				
Hde Back Forward Prix Options Contents Index Search 	😵 Help VSI 1.8				_		×
Hole Back Forward Pint Options Contents Index Search Installation and registration Image: Search in the se	\$3 ↔ ↔ 43 67-						
Contents Index Sparch □ Un General ② Installation and registration System requirements ③ Installation and registration ③ System requirements Introduction ③ Installation and registration ③ System requirements Introduction ③ Program ○ Prince Note of the possible fault code(s) in the system. ○ Program ○ Prince ○ Presciption VSI ECM ○ Prince ○ Presciption ○ Presciption ○ Presciption ○ Prince ○ Presciption ○ Presciption ○ Presciption ○ Prince ○ Presciption ○ Presciption ○ Presciption ○ Prince ○ Presciption ○ Presciption ○ Presciption ○ Presciption ○ Prince ○ Presciption ○ Presciption ○ Presciption ○ Presciption ○ Presciption ○ Prince ○ Presciption ○	Hide Back Forward Print Options						
Constraint Constraint <th>Contents Index Seamh</th> <th>Belov</th> <th>v an overview is given</th> <th>of the pr</th> <th>ossible fault code(s) in the</th> <th>system</th> <th>~</th>	Contents Index Seamh	Belov	v an overview is given	of the pr	ossible fault code(s) in the	system	~
Image: Second secon			v an overview is given	or the p		system.	
Instantation and registration Fault Description VSIECAI Solution Remark ② Introduction ③ Introduction ③ Introduction ③ Introduction ○ Introduction Introduction Introduction ○ Introduction Int	General Justallation and registration	fig1.8	: VSI fault codes				
Introduction Image: Software releases Image: Software releaseses Image: Software releases	System requirements	Fault	Description	VSI ECM action	Solution	Remark	
[®] Software releases [®] Program Program <t< td=""><td>2 Introduction</td><td>100</td><td>L1 Lambda is rich too long</td><td>-Petrol</td><td>Check whether a correctly</td><td>>\$105</td><td></td></t<>	2 Introduction	100	L1 Lambda is rich too long	-Petrol	Check whether a correctly	>\$105	
■ Derogram P1:1: Calibration manager P1:2: Save calibrations P1:2: Save calibrations P1:3: Open calibrations P1:3: Open calibrations P1:3: Open calibrations ■ F1: Process Parameters P1:5: Save calibrations ■ F1: Process Parameters P1:5: Save calibrations ■ F2: EGM VSI identification Petrol ■ F2: EGM VSI identification Petrol ■ F5: Reading VSI fault codes Petrol P1:1: Activating the ECM Petrol ■ F1: Process Parameter Settings Pit1: Activating the ECM ■ F1: Activating the ECM Petrol Duriversal Parameter Settings Pit1: Activating the petrol operation P U1:1 Parameter setting Petrol P U1:2 Noverview of parameters Pit1:3 Gas operation setting P U1:3 Overview of parameters Pit1:5 Gas operation setting P U1:5 Gas operation setting Pit1:0 T_ECT>=171C or voltage System LD 2 Hz System LD 1 T_LPG<=40C or voltage	Software releases			mode	regulating lambda signal is present	>\$205	
¹ P1.1: Calibration manager ¹ P1.2: Save calibrations ¹ P1.2: Save calibrations ¹ P1.3: Open calibrations ¹ P1.3: Open calibrations ¹ P1.2: Save calibrations ¹ P1.3: Open calibrations ¹ P1.3: Open calibrations ¹ P1.2: Save calibrations ¹ P1.3: Open calibrations ¹ P1.2: Save calibrations ¹ P1.3: Open calibrations ¹ P1.3: Open calibrations ¹ P1.2: Save calibrations ¹ P1.0: CMC, When this occurs ¹ during a long lasting FCO, you may have to configure the T1. min ¹ P2.CNG. ¹ P1.1: Activating the ECM ¹ P1.1: Activating the P2.0: Save calibration parameters ¹ P1.1: P1.2:	E 🛈 Program			-2 Hz beener	when driving on petrol and LPG/CNG.		
ⓐ 1 1.1. Solve calibrations ⓑ 1.3 Open calibrations mode -2 Hz beeper mode -2 Hz beeper mode regulating lambda signal is present when driving on petrol and LPG CNG. When this occurs during a long lasting FCO, you may have to configure the T1 min [38] parameter. >5105 @ F5: Read fault codes @ F5: Reading VSI fault cov @ F5: 2 Fault code table @ F7: Update the VSI ECM soft @ F1: Activating the ECM @ U1.1 Parameter Settings @ U1.1 Parameter setting @ U1.2 lipictor selection @ U1.3 Overview of parameters @ U1.4 Setting the petrol operat @ U1.5 Gas operation setting @ U1.6 Correction parameters @ U1.7 System selection @ U	P1.1: Calibration manager	101	L1 Lambda lean too long	-Petrol	Check whether a correctly	>\$105	
■ Unctions -2. Hz when driving on petrol and beeper ■ F1: Process Parameters -2. Hz beeper LPC(CNG, When this occurs during a long lasting FCO, you may have to configure the 11 min (38) parameter. ■ F5: Reading VSI fault code 2. F2 F1: Process Parameters >8105 ■ F5: Reading VSI fault code 2. F2 F1: Activating the ECM >8105 ■ F1: Activating the ECM 103 L2 Lambda lean too long -Petrol mode -2. Hz Check whether a correctly regulating lambda signal is present when driving on petrol and beeper >8005 I U1: 1 Parameter Settings 103 L2 Lambda lean too long -Petrol mode -2. Hz Check whether a correctly regulating lambda signal is present when driving on petrol and beeper >8105 I U1: 2 Injector selection ? U1: 2 Injector selection ? U1: 3 Overview of parameters ? Piol CNG, When this occurs during a long lasting FCO, you may have to configure the 11 min may have to configu	P1.3: Open calibrations			mode	regulating lambda signal is present	>\$205	
 Process Parameters F1: Process Parameters F2: ECM VSI identification F3: Reading Parameters F5: Read fault codes F5: Read fault code stable F5: Reading VSI fault coin F5: Provide the VSI ECM soft F11: Activating the ECM U1.1 Parameter Settings U1.1 Parameter Settings U1.2 Injector selection U1.3 Overview of parameters U1.4 Setting the petrol operat U1.5 Gas operation setting U1.6 Correction parameters U1.7 System selection T_ECT>=171C or voltage to object t	□ 🔟 Functions			-2 Hz	when driving on petrol and I PG/CNG. When this occurs		
■ F2: ECM VSI identification ■ F3: Changing Parameters ■ F5: Reading VSI fault codes ■ F5: Reading VSI fault code ■ F5: Pault code table ■ F5: Reading VSI fault code ■ F5: Reading VSI fault code ■ F5: Reading VSI fault code ■ F5: Lexabing VSI fault code ■ Universal Parameter Settings P U1: Parameter setting introd It 103 L2 Lambda lean too long -Petrol mode -2 Hz When driving on petrol and LPG/CNG. When this occurs Varing a long lasting FCO, you may have to configure the Ti min I38 It T_ECT>=171C or voltage System LED 2 Hz Check whethe	🗉 📚 F1: Process Parameters			beeper	during a long lasting FCO, you		
■ F3: Changing Parameters ■ F5: Reading VSI fault codes ② F5: Reading VSI fault codes ③ F5: Reading VSI fault codes ③ F5: Pault code table ■ ● <t< td=""><td>F2: ECM VSI identification</td><td></td><td></td><td></td><td>may have to configure the <u>Ti_min</u></td><td></td><td></td></t<>	F2: ECM VSI identification				may have to configure the <u>Ti_min</u>		
Image: Second radii codes []		102	I 2 Lambda is rich too long	Patrol	[38] parameter.	>\$105	
Image: Second secon	E5 1 Reading VSI fault could be added by the second s	102	L2 Lamoda is field too long	mode	regulating lambda signal is present	>\$205	
Image: Second secon	F5.2 Fault code table			-2 Hz	when driving on petrol and		
 F11: Activating the ECM □ Universal Parameter Settings ① U1.1 Parameter setting introd ② U1.2 Injector selection ③ U1.3 Overview of parameters ③ U1.4 Setting the petrol operation setting ③ U1.5 Gas operation setting ③ U1.6 Correction parameters ③ U1.7 System selection 110 T_ECT>=171C or voltage to low Check whether the blue connector of the coolant sensor on the vaporizer is connected to earth. 111 T_ECT<=-40C or voltage to high Check whether the blue connector of the coolant sensor on the vaporizer is connected to power supply. 120 T_LPG>=171C or voltage to high 120 T_LPG>=171C or voltage to high 120 T_LPG>=171C or voltage to high System LED 2 Hz Check whether the blue connector of the coolant sensor on the vaporizer is connected to power supply. 120 T_LPG>=171C or voltage to high System LED 2 Hz System to low Supply. Supply Supply		103	I 2 Lombdo loon too long	Deeper	Charle whether a corrective	S\$105	
□ Universal Parameter Settings ? U1.1 Parameter setting introd ? U1.1 Parameter setting introd ? U1.2 Injector selection ? U1.2 Injector selection ? U1.3 Overview of parameters ? U1.4 Setting the petrol operat ? ECT>=171C or voltage too low ? U1.5 Gas operation setting ? U1.6 Correction parameters ? U1.7 System selection * T_ECT>=171C or voltage too low 111 T_ECT<=-40C or voltage too high	E 📚 F11: Activating the ECM	105	L2 Lambda lean too long	mode	regulating lambda signal is present	>\$205	
Image: Section of the contrast	□ 🔟 Universal Parameter Settings			-2 Hz	when driving on petrol and		
Image: Second	UI.1 Parameter setting introd UI.1 2 Injector selection			beeper	during a long lasting FCO, you		
Image: Construct the set of the construction of the constructin on the construction of the construction of the cons	U1.3 Overview of parameters				may have to configure the Ti_min		
Image: Provide an expension of the contract of	U1.4 Setting the petrol operat				[38] parameter.		
Image: Contraction parameters Image: Contraction parameters Image: Contraction parameters Image: C	U1.5 Gas operation setting	110	T_ECT>=1/1C or voltage	-System	Check whether the blue connector of the coolant sensor on the	>\$105	
III T_ECT<=-40C or voltage too high	2 U1.6 Correction parameters		100 10 11		vaporizer is connected to earth.		
too high LED 2 Hz of the coolant sensor on the vaporizer is connected to power supply. >\$205 120 T_LPG>=171C or voltage too low -System LED 2 Hz Check the "pressure/temperature sensor" in the cover of the filter unit to determine whether it is connected to earth. >\$205 121 T_LPG<=-40C or voltage -System LED 2 Hz	O1.7 System selection	111	T_ECT<=-40C or voltage	-System	Check whether the blue connector	>\$105	
Image: state in the second state is the second st			too high	LED 2 Hz	of the coolant sensor on the	>\$205	
120 T_LPG>=171C or voltage too low -System LED 2 Hz Check the "pressure/temperature sensor" in the cover of the filter unit to determine whether it is connected to earth. >S105 121 T_LPG<=-40C or voltage -System heck the "pressure/temperature sensor" in the cover of the filter unit to determine whether it is connected to earth.					supply.		
too low LED 2 Hz sensor" in the cover of the filter unit to determine whether it is connected to earth. >\$205 I21 T_LPG<=-40C or voltage		120	T_LPG>=171C or voltage	-System	Check the "pressure/temperature	>\$105	
Image: Connected to earth. Image: Connected to earth. Image: Connected to earth.			too low	LED 2 Hz	sensor" in the cover of the filter	>\$205	
III T_LPG<=-40C or voltage -System heck the "pressure/temperature >S105					connected to earth.		
1 Line had been a second in the Cold City is 00002	< >	121	T_LPG<=-40C or voltage	-System	heck the "pressure/temperature	>\$105	\sim